

BABYSITS TILL CYKELVAGN



Step 1:

Install the upper strap of the hammock to the buckle according to the above photo showing.




Step 2:

Install the upper strap of the hammock to the buckle according to the above photo showing.




Step 3:

Install the upper strap of the hammock to the buckle according to the above photo showing.



Step 4:

After adjusting the position, secure the harness and fasteners.



Step 5:

Insert the hammock's waistband strap into the loop on the backrest shown in the picture above.



Step 6:

Tighten the strap on both side.

WARNING

Failure to follow these instructions could lead to serious injury or death.

Usage Requirements

This hammock is designed exclusively for infants who cannot yet sit upright without assistance. Only use this product if the child meets all of the following criteria:

Age: 1 to 10 months old.

Weight: Maximum 22 lbs (10 kg).

Height: Maximum 29.5 inches (75 cm).

Safety Precautions

Strolling Only: This product is intended for walking speeds only. Do not use for cycling. Using this hammock in a bike trailer poses a severe risk of injury or death.

Constant Supervision: Never leave your child unattended in the carrier.

Proper Installation: Ensure the hammock is securely fastened to the carrier's frame and seat. Refer to your owner's manual for detailed attachment instructions.

Secure the Harness: To prevent the child from falling or sliding out, always use the seat belt. The harness should be snug over the shoulders with the crotch strap positioned correctly between the legs.

IMPORTANT: Always consult the owner's manual for proper installation and harness adjustment before use.